

Service Manual

Cassette Deck
RS-M5
 (Silver Face)
 (Black Face)

Metal Tape Compatible Cassette Deck
 with Full Auto-Stop



This is the Service Manual for the following areas.

- ☐ For All European areas except United Kingdom.
☐ For United Kingdom.

RS-631 MECHANISM SERIES

Specifications

Power requirement:	AC; 110/220 V, 50-60 Hz for All European areas except United Kingdom	Fast forward and rewind time:	Approx. 86 seconds with C-60 cassette tape
	AC; 240 V, 50-60 Hz for United Kingdom	Inputs:	MIC; sensitivity 0.25 mV, input impedance 10 k Ω over applicable microphone impedance 400 Ω – 10 k Ω
Power consumption:	10 W	Outputs:	LINE; sensitivity 60 mV, input impedance 47 k Ω LINE; output level 420 mV, output impedance 1.4 k Ω or less, load impedance 22 k Ω over HEADPHONE; output level 60 mV, load impedance 8 Ω
Motor:	Electronic control DC motor	Rec/pb connection:	5 P DIN type; input sensitivity 0.25 mV, impedance 6.0 k Ω , output level 420 mV, impedance 5.0 k Ω
Track system:	4-track 2-channel stereo recording and playback	Bias frequency:	80 kHz
Tape speed:	4.8 cm/s	Heads:	2-head system; 1-MX head for record/playback 1-double-gap ferrite head for erasure
Wow and flutter:	0.07% (WRMS), $\pm 0.20\%$ (DIN)	Dimensions:	41.0 cm (W) $\times$ 14.2 cm (H) $\times$ 20.5 cm (D)
Frequency response:	Metal tape; 20–17,000 Hz 30–16,000 Hz (DIN) CrO ₂ tape; 20–16,000 Hz 30–15,000 Hz (DIN) Normal tape; 20–15,000 Hz 30–13,000 Hz (DIN)	Weight:	4.0 kg
Signal-to-noise ratio:	Dolby [*] NR in; 66 dB (above 5 kHz) Dolby NR out; 56 dB (signal level = max. recording level, CrO ₂ type tape)		

Specifications are subject to change without notice.

* 'Dolby' and the double-D symbol are trademarks of Dolby Laboratories.

Technics

Matsushita Electric Trading Co., Ltd.
 P.O. Box 288, Central Osaka Japan

Service Manual

Cassette Deck
RS-M5
 (Silver Face)
 (Black Face)

Metal Tape Compatible Cassette Deck
 with Full Auto-Stop



This is the Service Manual for the following areas.

- Ⓐ For All European areas except United Kingdom.
 Ⓑ For United Kingdom.

RS-631 MECHANISM SERIES

Specifications

Power requirement:	AC; 110/220 V, 50-60 Hz for All European areas except United Kingdom AC; 240 V, 50-60 Hz for United Kingdom	Fast forward and rewind time:	Approx. 86 seconds with C-60 cassette tape
Power consumption:	10 W	Inputs:	MIC; sensitivity 0.25 mV, input impedance 10 kΩ over applicable microphone impedance 400 Ω – 10 kΩ LINE; sensitivity 60 mV, input impedance 47 kΩ
Motor:	Electronic control DC motor	Outputs:	LINE; output level 420 mV, output impedance 1.4 kΩ or less, load impedance 22 kΩ over HEADPHONE; output level 60 mV, load impedance 8 Ω
Track system:	4-track 2-channel stereo recording and playback	Rec/pb connection:	5 P DIN type; input sensitivity 0.25 mV, impedance 6.0 kΩ output level 420 mV, impedance 5.0 kΩ
Tape speed:	4.8 cm/s	Bias frequency:	80 kHz
Wow and flutter:	0.07% (WRMS), ±0.20% (DIN)	Heads:	2-head system; 1-MX head for record/playback 1-double-gap ferrite head for erasure
Frequency response:	Metal tape; 20–17,000 Hz 30–16,000 Hz (DIN) CrO ₂ tape; 20–16,000 Hz 30–15,000 Hz (DIN) Normal tape; 20–15,000 Hz 30–13,000 Hz (DIN)	Dimensions:	41.0 cm (W) × 14.2 cm (H) × 20.5 cm (D)
Signal-to-noise ratio:	Dolby* NR in; 66 dB (above 5 kHz) Dolby NR out; 56 dB (signal level = max. recording level, CrO ₂ type tape)	Weight:	4.0 kg

Specifications are subject to change without notice.

* 'Dolby' and the double-D symbol are trademarks of Dolby Laboratories.

Technics

Matsushita Electric Trading Co., Ltd.
 P.O. Box 288, Central Osaka Japan

CONTENTS

ITEM	PAGE
LOCATION OF CONTROLS AND COMPONENTS	1
DISASSEMBLY INSTRUCTIONS.....	2
ASSEMBLY INSTRUCTIONS	3
ADJUSTMENT PARTS LOCATION	3
MEASUREMENT AND ADJUSTMENT METHODS	4—6
SCHEMATIC DIAGRAM	7
WIRING CONNECTION DIAGRAM.....	8
ELECTRICAL PARTS LOCATION	9
EXPLODED VIEWS	9, 10
CABINET PARTS	11

LOCATION OF CONTROLS AND COMPONENTS




Fig. 1

DISASSEMBLY INSTRUCTIONS




Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6

Procedure	To remove ———	Remove ———	Shown in fig. ———
1	Bottom cover	• 2 screws (A)	2
2	Front panel	• 1 screw (B) • 2 control knobs (C) • Cassette lid (D)	2 3 3
3	Operation button assembly and cassette holder	• 4 red screws (E)	4
4	Mechanism	• 6 red screws (F)	5
4	Main circuit board and oscillation circuit board	• 3 switch shelters (G) • 7 screws (H)	4 5, 6

ASSEMBLY INSTRUCTIONS

Caution:

Repair the cassette deck in its upright condition, as shown in fig. 7.
When mounting the main circuit board, lift the recording lever-A in the direction of the arrow, as shown in fig. 7.




Fig. 7

ADJUSTMENT PARTS LOCATION





Fig. 8

Caution:




Tape speed can be adjusted through the small hole on the back-side of main case by the $\ominus$ driver as shown in the diagram below.









MEASUREMENT AND ADJUSTMENT METHODS






NOTES: Keep good condition, set lever switches and controls in the following positions, unless otherwise specified.


- Make sure heads are clean.
- Make sure capstan and pressure roller are clean.
- Judgeable room temperature: $20 \pm 5^\circ\text{C}$ ($68 \pm 9^\circ\text{F}$)
- Dolby NR switch: OUT
- Tape selector: Normal position
- Input selector: Line in
- Input level control: Maximum

ITEM	MEASUREMENT & ADJUSTMENT
Ⓐ Head azimuth adjustment Condition: * Playback mode Equipment: * VTVM * Oscilloscope * Test tape (azimuth) ... QZZCFM * Test tape (tape path viewer) ... QZZCRD	Record/playback head azimuth adjustment 1. Test equipment connection is shown in fig. 9. 2. Playback azimuth tape (QZZCFM 8kHz). 3. Adjust record/playback head angle adjustment screw (A) in fig. 10 so that output level at LINE OUT becomes maximum. 4. Measure both channels, and adjust levels for equal output. 5. After adjustment lock head adjustment screw (A) with lacquer.  Fig. 9 Erase head azimuth adjustment 1. Test equipment connection is the same above but use the tape path viewer (QZZCRD) instead of test tape (QZZCFM). 2. Playback this tape. 3. Adjust screw (B) shown in fig. 11 so that the tape may not get curled or malformed by tape guide of the erase head. 4. After adjustment, lock head adjust screw (B) with lacquer.  Fig. 10  Fig. 11
Ⓑ Tape speed Condition: * Playback mode Equipment: * Digital electronic counter or frequency counter * Test tape ... QZZCWAT	Tape speed accuracy 1. Test equipment connection is shown in fig. 12. 2. Playback test tape (QZZCWAT 3,000Hz), and supply playback signal to digital electronic counter. 3. Measure this frequency. 4. On the basis of 3,000Hz, determine value by following formula: $\text{Tape speed accuracy} = \frac{f - 3,000}{3,000} \times 100 (\%)$ where, f = measured value 5. Take measurement at middle section of tape.  Fig. 12 Standard value: $\pm 1.5\%$

ITEM	MEASUREMENT & ADJUSTMENT
	Adjustment method 1. Playback the test tape (middle). 2. Adjust so that frequency becomes 3,000 Hz. 3. Tape speed adjustment VR shown in "Caution" on page 4. Tape speed fluctuation Make measurements in same manner as above (beginning, middle and end of tape), and determine the difference between maximum and minimum values and calculate as follows: $\text{Tape speed fluctuation} = \frac{f_1 - f_2}{3,000} \times 100 (\%)$ f_1 = maximum value, f_2 = minimum value Standard value: Less than 1%
Ⓒ Playback frequency response Condition: * Playback mode * Tape selector ... Normal position Equipment: * VTVM * Oscilloscope * Test tape ... QZZCFM	1. Test equipment connection is as same as "Head azimuth adjustment" (See fig. 9). 2. Place UNIT into playback mode. 3. Playback frequency response test tape. 4. Measure output level at 8 kHz, 4 kHz, 1 kHz, 315 Hz, 250 Hz, 125 Hz and 63 Hz, and compare each output level with standard frequency 315 Hz, at LINE OUT. 5. Make measurement for both channels. 6. Make sure that the measured value is within the range specified in the playback frequency response chart. Playback frequency response chart  Fig. 13
Ⓓ Playback gain Condition: * Playback mode * Tape selector ... Normal position Equipment: * VTVM * Oscilloscope * Test tape ... QZZCFM	1. Test equipment connection is shown in fig. 9. 2. Playback standard recording level portion on test tape (QZZCFM 315 Hz), and using VTVM measure the output level at LINE OUT. 3. Make measurement for both channels. Standard value: around 0.39 V Adjustment 1. If measured value is not within standard, adjust VR3 (L-CH), VR4 (R-CH) (See fig. 8). 2. After adjustment, check "Playback frequency response" again.
Ⓔ Bias leakage Condition: * Record mode * Input level control ... MAX * Tape selector ... Metal position Equipment: * VTVM * Oscilloscope	1. Test equipment connection is shown in fig. 14. 2. Place UNIT into record mode. 3. Adjust trap coils L5 (L-CH), L6 (R-CH), so that measured value becomes minimum. 4. Make adjustment for both channels.  Fig. 14
Ⓕ Erase current Condition: * Record mode * Tape selector ... Metal position Equipment: * VTVM * Oscilloscope	1. Test equipment connection is shown in fig. 15. 2. Place UNIT into record mode and measure voltage at test point 6. 3. Determine erase current with the following formula: $\text{Erase current (A)} = \frac{\text{Voltage across both ends of R304}}{1 (\Omega)}$ Standard value: around 155 mA (Tape selector ... Metal) 4. If measured value is not within standard, adjust as follows.  Fig. 15

ITEM	MEASUREMENT & ADJUSTMENT
	Adjustment - Open the point (A) and short the point (B) on the main circuit board in the wiring connection diagram (See page 8). - Make measurement for erase current. - Make sure that the measured value is within the erase current of 145 mA to 165 mA. - If it is beyond the value, carry out the following adjustments: - If the erase current is less than 145 mA, short the point (A). - If the erase current is more than 165 mA, open the points (A) and (B).
Ⓒ Bias current Condition: - Record mode - Tape selector - Normal position - CrO₂ position - Metal position Equipment: - VTVM - Oscilloscope	- Test equipment connection is shown in fig. 16. - Place UNIT into record mode, and tape selector to normal position. - Read voltage on VTVM and calculate bias current by following formula: $\text{Bias current (A)} = \frac{\text{Value read on VTVM (V)}}{10 (\Omega)}$ Standard value: around 400 μA (Normal position)  Fig. 16 - If measured value is not within standard, adjust VR301 (L-CH) and VR302 (R-CH) (See fig. 8 on page 3). - Set the tape selector to each position. - Make sure that the measured value is within standard. Standard value: around 550 μA (CrO₂ position), around 830 μA (Metal position)
Ⓗ Overall gain Condition: - Record/playback mode - Input level control ... MAX - Standard input level; - MIC ... -72 ± 4 dB - LINE IN ... -24 ± 3 dB Equipment: - VTVM - AF oscillator - ATT - Oscilloscope - Resistor (600 Ω) - Test tape (reference blank tape) - QZZCRA for Normal	- Test equipment connection is shown in fig. 17. - Place UNIT into record mode, and tape selector to normal position. - Supply 1 kHz signal (-24 dB) from AF oscillator, through ATT to LINE IN. - Adjust ATT until monitor level at LINE OUT becomes 0.39 V. - Using test tape, make recording. - Playback recorded tape, and make sure the value at LINE OUT on VTVM becomes 0.39 V (-7 dB). - If measured value is not 0.39 V, adjust VR5 (L-CH), VR6 (R-CH) (See fig. 8 on page 3). - Repeat from step (2).  Fig. 17
Ⓘ Overall frequency response Condition: - Record/playback mode - Tape selector - Normal position - CrO₂ position - Metal position - Input level control ... MAX Equipment: - VTVM - AF oscillator - ATT - Oscilloscope - Resistor (600 Ω) - Test tape (reference blank tape) - QZZCRA for Normal - QZZCRX for CrO₂ - QZZCRZ for Metal	Note: Before measuring and adjusting, make sure of the playback frequency response (For the method of measurement, please refer to the playback frequency response). - Test equipment connection is shown in fig. 17. - Place the test tape (QZZCRA) in the cassette holder. - Place UNIT into record mode, and tape selector to normal position. - Supply 1 kHz signal from AF oscillator through ATT to LINE IN.  Fig. 18


ITEM	MEASUREMENT & ADJUSTMENT
	- Adjust ATT so that input level is -20 dB below standard recording level (standard recording level = 0 VU). - At this time, LINE OUT level indicates 0.039 V. - Record each frequency 30 Hz, 100 Hz, 1 kHz, 4 kHz, 8 kHz and 10 kHz (12 kHz for CrO₂ and Metal). - Playback and express in dB the difference between playback output level of each frequency based on playback output level of 1 kHz. - Change test tape to CrO₂ (QZZCRX) and metal (QZZCRZ). - Set the tape selector to each position. - Measure as same as manner above. - Make sure that the measured value is within the range specified in the overall frequency response chart for CrO₂ and metal tape shown in fig. 18, 19 and 20.  Fig. 19  Fig. 20 Adjustment — Using bias current - When the frequency response between the middle and high frequency range becomes higher than the standard value, as shown by the solid line in fig. 21 increases, refer to bias current adjustment. - When it becomes lower, as shown by dotted line, refer to bias current adjustment.  Fig. 21 Note: For the method of bias current measurement, refer to "Bias current adjustment" on page 6.
Ⓛ Level meter Condition: - Record mode - Input level control ... MAX Equipment: - VTVM - AF oscillator - ATT - Oscilloscope - Resistor (600 Ω)	- Test equipment connection is shown in fig. 22. - Supply 1 kHz signal from the AF oscillator, through the ATT to the LINE IN. - Adjust ATT so that the monitor level at LINE OUT becomes 0.39 V. - Check to see that the level meter stays within the range of -1 dB to +1 dB. - If it is beyond the range, carry out the following adjustments: - Open soldered points (C) (L-CH) and (E) (R-CH) indicated as "DOWN" where level more than +1 dB. - Open soldered points (D) (L-CH) and (F) (R-CH) indicated as "UP" where level less than -1 dB.  Fig. 22
Ⓚ Dolby NR circuit Condition: - Record mode - Dolby NR switch ... IN/OUT - Input level control ... MAX Equipment: - VTVM - AF oscillator - ATT - Oscilloscope - Resistor (600 Ω)	- Test equipment connection is shown in fig. 23. - Place UNIT into record mode, set the Dolby NR switch to OUT position and supply to LINE IN to obtain -34.5 dB at TP7 (L-CH), TP8 (R-CH) (frequency 5 kHz). - Confirm that the value at IN position is 8 (± 2.5) dB greater than the value at OUT position of Dolby NR switch.  Fig. 23

[illegible]

HEMATIC DIAGRAM

Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Ref. No.	Part No.
RESISTORS			R91, 92	ERD25J104	C13, 14	ECEA1CS830
R1, 2	ERD25J100		R93, 94	ERD25J333	C15, 16	ECKD1H821KB
R3, 4	ERD25J562		R95, 96	ERD25J122	C17, 18	ECEA1HS100
R5, 6	ERD25J104		R97, 98	ERD25J271	C19	ECEA1CS331
R7, 8	ERD25J101		R99, 100	ERD25J331	C21, 22	ECFDD123KVV
R9, 10	ERD25J1823		R101, 102	ERD25J101	C23, 24	ECFDD183KVV
R11, 12	ERD25J121		R103, 104	ERD25J682	C25, 26	ECEA50MR33
R13, 14	ERD25J184		R105, 106	ERD25J273	C27, 28	ECEA1AS221
R15, 16	ERD25J274		R107, 108	ERD25J221	C29	ECEA1CS331
R17, 18	ERD25J682		R109, 110	ERD25J102	C31, 32	ECQM1H562JZ
R19, 20	ERD25J681		R111	ERD12ANJ330	C33, 34	ECQM1H472JZ
R21, 22, 23, 24			R113, 114	ERD25J102	C35, 36	ECQM1H273JZ
	ERD25J103		R117	ERD50FJ107	C37, 38	ECEA1HS100
R25	ERD25J561		R201	ERD50FJ101	C39, 40	ECEA50MR33
R27, 28	ERD25J472		R202	ERD25J683	C41, 42	ECFWD104MXY
R29, 30	ERD25J562		R203	ERD25J272	C43, 44	ECEA1HS100
R31, 32	ERD25J224		R204	ERD25J393	C45, 46	ECEA1J54R7
R33, 34	ERD25J1223		R205	ERD25J473	C47, 48	ECEA1HS100
R35, 36, 37, 38, 39, 40			R206	ERD25J102	C49, 50	ECFDD473KXY
	ERD25J102		R207	ERD25J103	C51, 52	ECKD1H471KB
R41, 42	ERD25J181		R211	ERD50FJ331	C53, 54	ECEA2A53R3
R43, 44	ERD25J105		R212	ERD50FJ391	C55	ECEA1ES101
R45, 46	ERD25J473		R213	ERD25J152	C57, 58	ECEA1HSR1
R47, 48	ERD25J332		R214	ERD25J681	C59, 60, 61, 62	ECEA1HS100
R49, 50	ERD25J474		R215	ERG12ANJ330		
R51, 52	ERD25J274		R216, 217	ERD50FJ101		
R53, 54	ERD25J184		R301	ERD25J100	C63, 64	ECFDD333KXY
R55, 56	ERD25J471		R302, 303	ERD25J562	C65, 66	ECFDD153KVV
R57, 58	ERD25J272		R304	ERD25J100	C67, 70	ECFDD393KXY
R59, 60	ERD25J471		R305	ERD25J561	C73, 74	ECFDD333KXY
R61	ERD50FJ101		R306	ERD25J103	C75, 76	ECFDD222KVV
R65, 66	ERD25J274		VARIABLE RESISTORS			
R67, 68	ERD25J393		VR1, 2	QVH3AA067A54	C81, 82	ECEA2AS010
R69, 70	ERD25J682		VR3, 4, 5, 6	EVNK4AA00B54	C83, 84	ECEA1HS100
R71, 72	ERD25J681		VR301, 302	EVNK4AA00B15	C85, 86	ECEA1AS470
R73, 74	ERD25J272		CAPACITORS			
R75, 76	ERD25J152		C1, 2	ECCD1H221K	C87	ECEA1CS221
R77, 78	ERD25J1473		C3, 4	ECEA25M4R7	C89, 90, 91, 92	ECKD1H102ZF
R79, 80	ERD25J101		C5, 6	ECCD1H221K	C93, 94	ECCD1H121K
R81, 82	ERD25J472		C7, 8	ECFWD102KVV	C95, 96	ECKD1H102ZF
R83, 84	ERD25J682		C9, 10	ECEA1CS330	C201, 202	ECEA1ES470
R85, 86	ERD25J472		C11, 12	ECFDD123KVV	C203	ECEA1CS330
R87, 88	ERD25J333				C204	ECEA2AS010
R89, 90	ERD25J123				C205	ECEA1ES101
TRANSFORMERS			TRANSISTORS			
T2	QLPD46EKC	Power Transformer	C212	ECKD1H103ZF		
*For All European areas except United Kingdom.			C213	ECEA1CS471		
	QLPA55EKC	"	C214	ECEA1HS100		
*For United Kingdom.			C215	ECEA1ES471		
T301	QLB0198K	Bias Oscillation Transformer	C301	ECEA1ES101		
COILS			C302	ECFDD123KVV		
L1, 2	QLM927	MPX Filter	C303	ECFDD222KVV		
L3, 4	QLQX0332K	Peaking Coil	C304	ECEA1ES331		
L5, 6	QLQC2721K	Bias Trap Coil	C305	ECEA1ES471		
L301	QLQX2421Y	RF Trap Coil	C306	ECFDD103KVV		
			C307	ECQP1183JZ		
SWITCHES			DIODES			
S1	QSS1205T	Slide Switch (Record/Playback Selector)	D1, 2, 3, 4	2SC1327		
S2	QES1490	Lever Switch (Tape Selector)	D5, 6	2SC945		
	"Silver Type"	"	D7	2SD592NCS		
	QES1485	"	D9, 10	2SC945		
	"Black Type"	"	Q11, 12	2SC1383		
S3	QES1491	Lever Switch (Input Selector)	Q13	2SC945		
	"Silver Type"	"	Q14	2SA564		
	QES1486	"	Q16	2SC1846		
	"Black Type"	"	Q301	2SD592NCS		
S4	QES1492	Lever Switch (Dolby IN/OUT Selector)	Q302	2SC1568		
	"Silver Type"	"				
	QES1487	"				
	"Black Type"	"				
S5	QSW2214A	Push Switch (Power ON/OFF)				
S6	QSR1409H	Rotary Switch (AC Power Voltage Selector)	D1, 2, 3, 4	20A90		
*For All European areas except United Kingdom.			D5, 6	MA161		
S7	QSB0247	Leaf Switch (Motor ON/OFF)	D7	0A91		
FUSES			D8	MA161		
F1	XBAQ0007	Fuse (T 400mA)	D9	SVDEQA0113RA		
F2, 3	XBAQ0013	Fuse (T 200mA)	D10	LN213RP		
JACKS			D11, 12, 13, 14, 15	SM112		
J1	QJA0257H	Microphone Jack	D301, 302, 303, 304	SM112		
J2	QJA0249C	Headphone Jack	D305	SVDR016EB		
J3	QJS1954H	Record/Playback Connection Socket	D306	MA161		
			INTEGRATED CIRCUITS			
			IC1, 2	NE646B		


WIRING CONNECTION DIAGRAM



※For All European areas except United Kingdom.

※For United Kingdom.


ELECTRICAL PARTS LOCATION




NOTE: Δ indicates that only parts specified by the manufacturer be used for safety.

Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description
ELECTRICAL PARTS								
E1	QWY4122Z	Record/Playback Head	E10	XTN3+16B	Tapping Screw $\varnothing 3 \times 16$	E22	QMA3841	Microphone Holder
E2	QWY2138Z	Erase Head	E11	QMA3893	Volume Angle	E23	RME144ZA	Cord Clamper
E3	QML3568	Recording Lever-A	E12	QKJ0381	Level Meter Holder	E24	QMA3960	Circuit Board Angle
E4	QML3569	Recording Lever-B	E13	QBG1366	Rubber Bush	E25	QZE0003	Porcelain Tube
E5	QXR0667	Power Button Assembly	E14	QSL1109NM	Level Meter	E26	QJT1067	Check Pin
	"Silver Type"	"	E15	QNQ1004	Nut 8 ϕ	E27	QJP1921TNL	3 Pin Post
	QXR0667K	"	E16	QNQ2002	Washer	E28	QJS1921TN	3 Pin Socket
	"Black Type"	"	E17	QNQ1070	Nut 12 ϕ	E29	QJP1922TNL	6 Pin Post
E6	QMA3840	Earth Plate	E18	Δ QTF1054	Fuse Holder	E30	QJS1922TN	6 Pin Socket
E7	Δ QFC1204M	AC Power Cord	E19	XAMQ21P100N	Pilot Lamp	E31	QJT1054	Contact
※For All European areas except United Kingdom.			E20	QFC2135	Pin Cord	E32	XTN3+8B	Tapping Screw $\varnothing 3 \times 8$
Δ QFC1205M			E21	QKJ0382H	Cord Clamper	E33	XSN3+8S	Screw $\varnothing 3 \times 8$
※For United Kingdom.				"	"	E34	XWA3B	Washer
E8	QTD1164	Cord Bushing		"	"	E35	Δ QKJ0395	Spacer
E9	XTN3+10B	Tapping Screw $\varnothing 3 \times 10$		"	"	※For All European areas except United Kingdom.		
						E36	XSN3+6	Screw $\varnothing 3 \times 6$
						E37	QJT0015	Lug Terminal

EXPLODED VIEWS



Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description
MECHANICAL PARTS								
M1	QML2898	Pause Lock Plate	M27	QML3217	Pause Lever	M62	QBC1350	Safety Lever Spring
M2	QMK1829	Head Base Plate	M28	QML3124	Lock Release Arm			
M6	QXL1057	Pressure Roller Lever Assembly	M30	QMR1735	Lock Rod Assembly	M63	QBN1513	Idle Spring
M7	QXI0098	Takeup Idler Assembly	M31	QXR0342	Pause Rod Assembly	M65	QBN1574	Brake Spring
M8	QML3051	Erase Safety Lever	M32	QXR0465	Record Rod Assembly	M66	QBC1344	Back Tension Spring
M10	QDK1012	Steel Ball 2.5 ϕ				M67	QBN1555	Pause Spring
M11	QKG2997	Chassis Cover	M33	QXR0344	Playback Rod Assembly	M68	QBP1664	Operation Rod Spring
M12	QMA3169	Shaft Reinforcement Angle	M34	QMR1624	Rewind Rod-A	M70	QBP1662	Lock Rod Spring
M13	QXF0163	Flywheel Assembly	M35	QMR1623	Fast Forward Rod-A	M71	QBT1682	Lock Holding Spring
M14	QXH0239	Flywheel Retainer Assembly	M36	QMR1622	Stop Rod-A	M75	QBW2008	Snap Ring 2 ϕ
			M37	QMR1621	Eject Rod-A	M76	QBW2046	Snap Ring 3 ϕ
			M38	QML3038	Switch Arm	M77	XUB4FT	Stop Ring C4 ϕ
			M39	QML3287	Brake Lever			
M15	MMI6A2LKPA	Motor	M40	QDB0240	Counter Belt	M79	QHQ1226	Head Adjustment Screw
M16	QXP0513	Motor Pulley Assembly	M41	QXC0049	Tape Counter	M80	XSN2+10	Screw $\varnothing 2 \times 10$
M17	QDB0219	Flywheel Belt		"Silver Type"	"	M81	XTN26+6B	Tapping Screw $\varnothing 2.6 \times 6$
M18	QXL1136	Fast Forward Arm Assembly		QXC0041	"	M82	XTN3+10B	Tapping Screw $\varnothing 3 \times 10$
M18-1	QBN1517	Fast Forward Spring		"Black Type"	"	M83	XTN26+8B	Tapping Screw $\varnothing 2.6 \times 8$
M18-2	QBN1559	Fast Forward Arm Spring	M42	QMA3676	Counter Angle	M84	XSN26+3	Screw $\varnothing 2.6 \times 3$
M18-3	QMC0080	Collar				M85	XTN3+25B	Tapping Screw $\varnothing 3 \times 25$
M19	QML3040	Cam Lever	M47	QXR0403	Eject Rod-B	M86	XTN26+6B	Tapping Screw $\varnothing 2.6 \times 6$
M20	QXD0067	Takeup Reel Table Assembly	M47-1	QBT1619	Idle Spring	M87	QML3504	Cue Lever
M21	QXD0084	Supply Reel Table Assembly	M48	QMA3414	Motor Angle	M88	QML3207	Muting Lever
			M51	QXG1031	Damper Gear Assembly			
M22	QXL1384	Auto-Stop Lever Assembly	M56	QBC1278	Head Spring	M89	QBW2012	Snap Ring
M23	QDG1096	Cam Gear	M57	QBP1841	Head Base Plate Pressure Spring	M90	QBC1103	Head Spring
M24	QXG1026	Auto-Stop Gear Assembly	M58	QBN1488	Pressure Roller Spring	M91	QDG1116	Capstan Gear
M25	QXL1037	Gear Lever Assembly	M59	QBN1733	Playback Spring	M92	QBC1301	Capstan Spring
M26	QML3042	Auto-Stop Obstruction Lever	M60	QBN1480	Pause Lock Spring	M93	QBW2049	Snap Ring





SPECIFICATIONS

Pressure of pressure roller	350 ± 50 g
Takeup tension * Use cassette torque meter ... QZZSRKCT	50 ± 15 g·cm
Wow and flutter (JIS) * Use test tape ... QZZCWAT	Less than 0.12% (WRMS)

CABINET PARTS

Ref. No.	Part No.	Part Name & Description
CABINET PARTS		
G1	QKM1417H "Silver Type" QKM1385K "Black Type"	Main Case
*For All European areas except United Kingdom.		
	QKM1408H	"
*For United Kingdom.		
G2	QKA1081	Case Foot
G3	QKG2998	Switch Shelter
G4	QYT0572 "Silver Type" QYT0583 "Black Type"	Volume Knob Assembly
G5	QYF0434 "Silver Type" QYF0443 "Black Type"	Cassette Lid Assembly
G6	XTB3+8BFN "Silver Type" XTB3+10BFZ "Black Type"	Tapping Screw $\pm 3 \times 8$ Tapping Screw $\pm 3 \times 10$
G7	QYP0951 "Silver Type" QYP0951K "Black Type"	Front Panel Assembly
G8	QGC1176	Bottom Cover
G9	QKA1083	Rubber Foot
G10	QH01299	Screw $\pm 3 \times 8$
G11	QKJ0385	Spacer
G12	XTN26+6	Tapping Screw $\pm 2.6 \times 6$
G13	QGS2810 "Silver Type" QGS2812 "Black Type"	Main Name Plate
*For All European areas except United Kingdom.		
*For United Kingdom.		
G14	QG01580 "Silver Type" QG01593 "Black Type"	Pause Button
G15	QG01579 "Silver Type" QG01592 "Black Type"	Record Button
G16	QG01578 "Silver Type" QG01591 "Black Type"	Playback Button



Ref. No.	Part No.	Part Name & Description
G17	QG01577 "Silver Type" QG01590 "Black Type"	Rewind Button
G18	QG01576 "Silver Type" QG01589 "Black Type"	Fast Forward Button
G19	QG01575 "Silver Type" QG01588 "Black Type"	Stop Button
G20	QG01574 "Silver Type" QG01587 "Black Type"	Eject Button
G21	XUC4FT	Stop Ring 4 ϕ
G22	QMN1861	Push Button Shaft-B
G23	QMN2535	Push Button Shaft-A
G24	QXA0720	Push Button Holding Angle Assembly
G25	QKF6011	Cassette Holder
G26	QBP1818	Holder Spring
G27	XTN26+6B	Tapping Screw $\pm 2.6 \times 6$
G28	QBN1641	Lid Spring
G29	XUC3FT	Stop Ring 3 ϕ
ACCESSORIES		
A1	QQT2799	Instruction Book
*For All European areas except United Kingdom.		
	QQT2820	"
*For United Kingdom.		
PACKINGS		
P1	QPN4006	Inside Carton
P2	QPA0516	Cushion
P3	XZB40X60A02	Poly Bag
P4	QPS0477	Pad
P5	QPS0432	Spacer